






PROCOM - USER HANDBOOK



PROCOM System Layout



Central Unit, connections






Line Termination Box LTB-500

TWC-500

Sensor common
Pump Alarm
Rain Sensor

Line B
Line A





Installation of software

PC-program:

Insert the CD with the software and follow the instructions on the screen. If the Installation program does not start automatically, use the command <CD-drive>:Install.

Controller program:

The software in the Controller is stored in memory which is supplied from a backup battery. This means that a new version can be delivered on a disk and easily "downloaded" from the PC. Software is normally preinstalled.

If you need to install the Controller software, select the COM Port from the System menu.

It is not possible to perform a download via a modem/telephone connection!



When the COM-port is selected, Select "Download CU Software". This will open a file window where you select the Controller Software file (procom.hex), click on <Open> and follow the instructions on the screen. The progress can be monitored in the messages on the screen. The steps are transfer of the data and storing ("flashing 4 times") of data in the permanent memory. The procedure takes about 8 minutes and is finished when the message "Program is now running" appears.

Menu Tree



The program has two main sections, the Installation Data and the Irrigation Part.

The Installation Data is a database which contains all information about Pumps, Pipes, Decoders and sensors. To write Schedules the names/addresses of the decoders must be in the data base and detailed information about the hydraulic properties of the system is necessary for the "Flow Optimizer" to work.

To enter the installation section, either select "Installation Data" from the Main Menu or click on the icon:



Note: Menus in italics are not yet available



Parameters

Max. number active Solenoids.

The Controller is rated for 40* simultaneously active solenoids (28 Ohms/2 W). If the resistance is lower, the maximum number must be reduced proportionally.

*2 sections with 20 each, more about this later.

Legal Characters. Do not change see Line Decoders.



Power Off time.

If a power failure occurs during irrigation, the controller is able to resume the watering where it was interrupted. If the time is set to zero, irrigation will not be resumed. If the power outage is less than the set time, watering will resume exactly where it stopped. If the outage is more than the set time, the schedule will resume with what is scheduled for that time (there will be a "hole" in the schedule).

ET is not yet implemented.

Measurement Units.

The data are not converted when other unit systems are selected. It is therefore important to select the units before entering the data.



(Installers) Password

To protect the Installation Data from being changed by unauthorized persons, it is recommended to use password protection. When password is used the field changes from grey to colored. If you click on a green password field, protection is on and the field changes to red.

To remove protection, click on the red field and enter the password as prompted.



Remove password

Select password from the Setup Menu and enter the current password. The two boxes for the new password must be left empty. Click the OK button and the password is removed. Accordingly the field becomes grey.

Password Definition

Type current Password:

Type New Password:

Type New Password AGAIN:

User Passwd

Inst. Passwd

Main Pipe

The Main Pipe is equal to the pump manifold and no valves can be connected to it. The capacity shall of course be the same as the pump capacity.

The pipe model used by the Flow Organizer is a tree structure and other layouts must therefore be transformed into such an approximation.

Section of Main Pipe

Main Pipe

Capacity (Gpm):

Pump Capacity load Factor:

Slave Pump, use 0 for none:

Connected to:

New Pipe

To add pipe sections the model, select "New Pipe" from the menu and enter the capacity of that pipe. Observe that the layout is completed with a new pipe marked "Section 1". You may drag Section 1 to a position that suits you.

Section 1 can only be connected to the Main Pipe but subsequent sections may be connected to other sections by use of the drop down menu at the bottom of the table.

TWC-500 - Installation

Setup Pipes Valves Pumps Sensors

Main Pipe

New Pipe

Section 1

Main Pipe

New Pipe

Pipe section 1

Capacity (Gpm):

Pump Capacity load Factor:

Slave Pump, use 0 for none:

Connected to:

[illegible]

Type of Valves

A Valve Type is determined by the following:

- Capacity** (which is needed by the Flow Optimizer)
- Precipitation rate** (which is needed for ET control of irrigation)
- Resistance** (of solenoid which is needed by the System Tests)
- Electric code** (which is necessary to operate the valve)
- Number of solenoids** (which is necessary not to overload the system)

If just one of these factors changes it is necessary to create a new Valve Type. Up to 100 Valve Types may be created.

[illegible]

Line Decoders

The table is the link between the **Name** you want to use for the decoder and the **Address** on the decoder label. For the names you can use up to 8 characters. You may use any letter/digit combination, but if you want to use the Field Access Unit (FA-100) your choice is limited to the "Legal Characters" (see page 6).

If a number is already used by another Decoder, a warning will be shown. Duplicate numbers are permitted, but should normally be avoided.

For each Line Decoder you must also list the following:

- Valve Type
-Decoder Type: 1=LD-100
2=LD-200
4=LD-400
6=LD-600

This information is needed for the Test Program to calculate correctly the standby current.

-Pipe Section

The button with the "down arrow" takes you to the end of the list.



Pump Decoder

Up to 16 pumps may be defined, each with its own capacity and Pump Decoder. Line Decoders may be used to control pumps but they must be defined as Pump Decoders.

For each Pump number, the system suggests an **Address**. The Pump numbers are created automatically and correspond to the switch positions on the Pump Decoder:

P1: 284 P4: 292
P2: 286 P5: 293
P3: 287 P6: 295
P7: 296 P8: 310

Priority can range from 0 to 6. Priority 1 is the highest, i.e. this pump is started first. More pumps with the same priority take turns to start first. Priority 0 corresponds to no Pump Decoder installed. A slave (booster) pump must be installed with priority 5.

On-delay is the time in seconds from the pump is turned on and till a following pump can be started.

Off-delay is the time in seconds from the end of demand and till the pump is actually stopped.

Pump	Address	Status	Capacity	Priority	On-delay	Off-delay	Electric
1	284	Installed	2000	1	0	10	45A20
Total	0	Not Installed	0	0	0	10	45A20

A slave pump is a pump that must be started whenever valves on a certain pipe section are turned on. When the slave pump has been defined in this table, open the window for that pipe section and enter the pump number in the "Slave Pump" field. The capacity of a slave pump is not included in the total pump capacity.

Sensor Inputs

Rain Sensor

When the sensor is activated by rain, all Line Decoders and pumps are immediately stopped and the message RAIN is displayed in the status field. Decoders may be started manually. When the Sensor returns to the passive mode, Irrigation will resume.

Alarm Sensor

Input may come from a pump, a pressure gauge or similar. When the sensor is active, Line Decoders can not be started neither by Irrigation Schedules nor manually. The status displays ALARM

Name	Status	Type
** Rain Check **	Not Installed	On, Closed
* Alarm Sensor *	Not Installed	On, Closed
* Line Voltage *	Installed	On, Open
* Short Circuit *	Installed	On, Closed

A Sensor that is not installed shall be set to NOT INSTALLED. To use a sensor it shall be installed as either ON, CLOSED (Normally Open) or as ON, OPEN (Normally Closed). A Rain Gauge which acts as an off-switch during rain and as a short-circuiter during dry periods, shall be installed as ON, OPEN. Sensors 1 and 2 may be disabled by changing their status to NOT USED in the Sensor Status menu. All sensors have a response time of about 1 minute from the physical activation till the status changes on the screen.




Sensor inputs		
Name	Status	Type
** Rain Check **	Not Installed	On, Closed
* Alarm Sensor *	Not Installed	On, Closed
* Line Voltage *	Installed	On, Open
* Short Circuit*	Installed	On, Closed

The **Line Voltage Sensor** monitors the voltage between the 2-wire and ground. If a fault is detected, a relay automatically disconnects the Line and the message ERROR is displayed in the status field. This will cause all decoders and pumps to stop. After the fault is removed, the Central Unit must be turned off and on again to restore operation. Sensor 3 is by default ON, OPEN.

Line Voltage & Short Circuit


These two sensors are internal (in the Line Control Module). They monitor the conditions on the Lines and their status can not be changed.

The **Short Circuit** sensor monitors the voltage on the line. If the voltage drops below the set limit (default 25 Volts), the line voltage is set to zero and the message SHORT is displayed in the status field. Every 10 minutes the Line voltage will be applied again for one minute to check if there is still a short. Sensor 4 is by default ON, CLOSED.



Date and Time

Select from the Installation Data menu "Date and Time". Note that Military Time is used. 6:13 PM must therefore be entered as 18:13.



Flow Sensor

From the Sensors menu select Edit Sensor Decoder. Now you have to key in the information needed to set up the flow sensor.



Sensor Decoder

The address of the Sensor Decoder is printed on the decoder label.

Calibration Data

This information is necessary for the Controller to convert the measurement into GPM. In the example 917 pulses counted over 10 seconds correspond to 250 GPM. The actual numbers depend on the flow sensor and the pipe size.

Pulse/10 seconds are mostly used with impeller type flow meters.

ms/pulse (milli-seconds between pulses) is used with sensors that give a small number of pulses per second.

mA (4-20 mA) is an industrial type of sensor.

High Flow alarm

If the flow exceeds 50 GPM for more than 2 minutes, an alarm will be triggered. The controller reacts by stopping all decoders in the current step and calling the pager (phone) 712 223 1221 which will display the message 1111.

Leakage alarm

If the flow exceeds 5 GPM for more than 2 minutes the Controller will activate the decoder MV and call the pager to display the message 0000.

The action can be "Activate" or "Deactivate" and the decoder can be any decoder in the installation or all decoders.

If your controller is connected to more than one Flow sensor you can set up the others in the same way by pressing "Next".

Flow sensor

Sensor # Name

Definition

Flow @ Units ☐ Log flow to file

Units

- Pulse/10s
- Not installed
- Pulse/10s
- ms/pulse
- mA

If you check this box all flow measurements will be logged in the monitor file.

Alarm - high

Stop irrigation when flow is above

Call #, followed by message

Alarm - leak

decoder when flow is above

Call #, followed by message



Flow Sensor Edit V1.4 - []

Flow displayed on controller

Sensor #	1	2	3	4	5	6	7	8	9	10	
	☒	☒	☐	☐	☐	☐	☐	☐	☐	☐	☒ Log flow to file

Alarm - high

Stop irrigation when flow is above

Call #, followed by message

Alarm - leak

decoder when flow is above

Call #, followed by message

Necessary to get
flow measurements
in the Logviewer

When you have defined all Flow sensors, press "Done" and this window will appear. Here you can sum the measurements from all sensors and set up the total flow to trigger alarms and log the measurements to the monitor file in the same way as for the individual flows.

When you press "Finish", the data setup for the sensor decoders will be stored in the database on the PC.

Flow Monitoring

Measurements from the Sensor Decoders are used in two different ways:

Alarm trigger, i.e. if a certain event happens, the controller will react in a certain way (refer to the previous pages).

Monitoring the system, i.e. the water flow. The controller stores in memory all events : Start a Decoder , stop a Decoder, reading of a Flow Sensor. This is useful if you have several water sources and you want to keep track of the flow rates from each water source. The measurements are stored in the monitor file and can be seen in the Monitor screen. If you use the **'Extract and View'** function the data are presented with the "Show Data" function.

The flow measurements made by a specific Flow Sensor is stored in the monitor file only if you check this box.

Definition

Flow @ Units ☐ Log flow to file



Using the Flow summing will allow you to monitor the sum of several flow sensors (in this example 3 sensors are installed but we only want to sum number 1 and 2).

The sum as defined here is stored in the monitor file where it is used to calculate the water consumption. Can be viewed in "Extract and view" using the "Show overview" function (Refer to page 32 Monitoring Data for more details.)

If you want to use the flow measurements to calculate the water consumption, you must check this box.

Flow displayed on controller



Sensor #	1	2	3	4	5	6	7	8	9	10	
	☒	☒	☐	☐	☐	☐	☐	☐	☐	☐	☒ Log flow to file


Transfer of Data

All changes of data are stored in the PC. For the controller to irrigate according to these data they must be transferred from the PC to the controller. There are 3 buttons like this:



which may be used to initiate transfer of data. When transfer is necessary the 3 buttons change appearance as shown in the left picture. When transfer is complete, the buttons change as shown in the right picture.






Connect

Transfer is not possible if the PC and the Controller are not connected. If the indicator on the toolbar of the main screen is "Off line" (red), click on it and the Communication Status window appears. In this window, click on the connect button to establish the contact.

The Status Field will show current status.

The Message Window will report current actions so that you can monitor the progress. The data transfer consists of the following blocks:

- Sensor Decoders
- General System Data
- Installation Data
- Irrigation Schedules



Modem connection

If you are operating the Controller remotely, you need to change the Connection setup to Modem and enter the Phone number of the remote installation.

When operating the system via a telephone line it is too costly to be connected all the time. When you want to disconnect, click on the Disconnect button in the Communication Status window. The indicator on the toolbar of the main screen will change to Off line when disconnected.



Test of installation

When the installation is finished it is recommended to perform the following (automatic) tests:

- ID short
- GF solenoids
- GF signal

Solenoid resistance

To enable the automatic measuring facilities it is necessary to key values for the solenoids resistances.

Typically the resistance is 28 Ohms. If two such solenoids are paralleled the resistance must be set to 14 Ohms.

With the default value (0 Ohms) all valves with that valve type is skipped in the automatic tests.

ID	Capacity	Apply Rate	Resistance	Electric	No Solenoids
1	10.00	0.00	28	50F350	1
2	6.0	0.00	14	50F350	2
3	0	0.00	0	50F350	1


True monitoring

Valve types which are defined with a resistance from 1-50 Ohms are checked for proper operation when activated in Irrigation Schedules. If the solenoid does not respond correctly, the valve will be closed and an error message shown in the monitoring. Instead of the flow is shown the current when the valve is started.


In this example L6 and L7 has an error. Current is 59 and 60 mA. Note that the valves are stopped a few seconds after they are started and note also the message IS STOPPED at the time where L6 is scheduled to stop.

Event	Time	Current (mA)
PUMP 3 STARTED	Mon Jan 22 13:31:13 2001	
L6 STARTED	Mon Jan 22 13:31:13 2001	72
L6 ***** ERROR	Mon Jan 22 13:31:16 2001	59
L7 STARTED	Mon Jan 22 13:31:16 2001	84
L7 ***** ERROR	Mon Jan 22 13:31:18 2001	60
PUMP 4 STARTED	Mon Jan 22 13:31:18 2001	
L4 STOPPED	Mon Jan 22 13:31:18 2001	72
PUMP 4 STOPPED	Mon Jan 22 13:31:19 2001	
L5 STOPPED	Mon Jan 22 13:31:19 2001	60
L6 STOPPED	Mon Jan 22 13:31:19 2001	48
PUMP 3 STOPPED	Mon Jan 22 13:31:20 2001	
L7 STOPPED	Mon Jan 22 13:31:20 2001	36
GPH	Mon Jan 22 13:32:02 2001	89
L6 IS STOPPED	Mon Jan 22 13:34:01 2001	36
Flux10	Mon Jan 22 13:34:01 2001	89


From: 2001.01.21 To: 2001.01.23 01 Lines: 48 Mode: Freeze Status: Ready



Automatic testing



This test will go through all the valves in the order they are listed in the database. Every time a valve does not respond properly, the name and measurement results are displayed in the window. In this example decoder L6 did not respond: The 3 currents representing standby-inrush- and holding currents are all the same. The number displayed after the decoders is its address. Decoders L4 through L12 and MV are not tested because their valve type resistance is set to zero.



Important!


Before you perform the "GF" and the "LD thorough" test, you must have done the "LD short" and corrected any faults found in that test. If you do not correct the faults before proceeding the decoders will fail in the other two tests as well.



GF Solenoids


The test offers a choice of 3 voltage levels for the testing. Test level 1 (15 Volts) will search for only severe leakages as compared to test level 3 (35 Volts) which will search for very small leakages.


Unless there are many and severe leakages it is recommended to start at level 3. If there are many faults the test should be repeated after repairing the faults because many heavy faults may cover up for the minor leakages.



Reprogramming


After selection of the test voltage the test will start with reprogramming of all decoders followed by a period of 5 minutes where the two lines are automatically connected together and supplied with the line voltage (of the level selected), with respect to ground.





After the 5 min's period the normal line voltage is applied again, and the test "LD short" is run automatically.

During this rest all leaky positions are displayed with measurements result on the screen. The three current values represent (as before) standby-, inrush- and holding currents.




GF signal

In this case there is a leakage of 18 mA on the lines. See Line Survey on page 22.





LD Thorough

This test checks the standby current of each Line Decoder. After programming of all decoders, the Line Voltage is interrupted for approximately one minute. Line voltage is then reestablished and all Decoders are tested for correct response.



Any Decoder that does not respond has an abnormal consumption and should be replaced.






Manual Tests

Line Decoder

A given number of current measurements will be made each time a decoder is tested. The time interval will set the time between each measure taken. The value of the time interval is user definable and can be set from 5 ms to 100 ms. The default value is 20 ms. In our example you may verify the standby, inrush and holding to 34, 482 and 56 mA.



If you want to start with a specific decoder, click on the button with the question mark and select the one from the drop down list. If you do not select a specific one, the test program will start with the first in the installation. When the readings appear you may stop the valve and start the next.



Digital Voltmeter



Clampmeter



The necessary instruments for servicing the irrigation system is a digital voltmeter and a clampmeter. If the voltmeter is used only to check voltages on the system, a resolution of 1 V is sufficient.


The clampmeter can be either a probe connected to a voltmeter or a separate instrument. In the first case the voltmeter must have a resolution of 1 mV (AC). Observe that although the resolution is 1 mV the accuracy is typically ± 3 mV. The probe must have a resolution of 1 mA. For the probe a conversion of 1 mA to 1 mV would be normal. As a separate instrument, it is difficult to find one with a measuring range down to 1 mA. Most of these are designed for power applications and minimum ranges of 1 A are the usual. Normally clampmeters register only AC current but it is possible to get meters that register DC currents as well, but those are more expensive.

A problem common to both the voltmeter and the clampmeter is the frequency of the AC in the system. AC meters are normally designed for frequencies from 50 Hz to 1000 Hz (mains frequency is 60 Hz). The frequency of the Flowmaster system is 1 Hz, but more about this in connection with the individual measurements.

Short Finding

Select "Electrical Measurement" From the manual Test Menu. When you press "Run Test" the AC Line voltage will change from 1 cycle/sec to 50 cycles/sec which can be measured with a clampmeter.

Start with measuring the currents on the Lines at the LTB-500. If more than one Line has shorts, check one at a time by disconnecting the others. In case of a loop, disconnect one end. Follow current through the Line until it disappears indicating that you have passed the shortening point. A precise "as built" diagram saves time.



M3FW Test Manual [X]

LCM | Line Dec. | Pump Dec. | Elec. Meas. | Ground Fault | **Line Survey**

Line Survey - [LCM version 218]

Current 34mA (34mA+0mA)	Expected Stand-by Current: 16mA
- Limit 1099 mA	Line 1
Voltage 35.6V	Line 2
Threshold Low 10.0 V High 25.0 V	Line 1 Connections: - ☐ None ☐ + Line 2 Connections: - ☐ None ☐ +
Earth References Voltage @ the case 1.8V (20.1 V) Current 2mA Voltage internal 1.8V (20.1V) Threshold -0.8V (17.5 V)	

Line Survey

This screen gives an overview of voltages and currents in the system. Values are updated every second, but not all at the same time. This means that when values are varying with time, the readings shown on the screen does not correspond.

Current 34mA (34mA+0mA)	Expected Stand-by Current: 16mA
- Limit 1099 mA	Line 1
	Line 2

This part contains Line current. The limit is the current where the voltage is regulated down to prevent overload. The expected current is calculated on basis of the number of Line Decoders in the installation data base. The difference between single and multiple Decoders is of course considered.

Voltage 35.6V
Threshold Low 10.0 V High 25.0 V

Line 1
Line 2

The voltage is the Line voltage measured on the output of the controller. When the voltage drops below the high threshold, the line power is shut off. The low threshold is used when the Field Access unit communicates. The Line 1 and Line 2 fields alternate red/green to simulate the AC but are not synchronized with the actual Line Voltage.

Earth References	
Voltage @ the case 1.8V (20.1 V)	Current 2mA
Voltage internal 1.8V (20.1V)	Threshold -0.8V (17.5 V)

This box shows values of the Ground Voltage system for corrosion protection. Voltage "@ the case" is the Ground Voltage referenced to the negative line. When this voltage reaches the threshold, Line Voltage is shut off. The current is the leakage current. Internal voltage is the reference for the Ground Voltage regulator.




Irrigation Schedules

Select from the Irrigation Menu to bring up the window which is the "base" when writing schedules.

Schedule Name

Click on the Name field to make it active and write the name you want for your schedule.



Week Days


Click on the days field to bring up a table with the 2 weeks which are the programming period. To know which week is the current, open the View/Status window. In the Date and Time field there is a number in parenthesis after the date. That number is the day number in a 14 day cycle. In the example the current day is Wednesday of the second week. When you close the window, the marked days are shown in the days field.



Start Times

click on the "Start Times" field to open the table and key in the desired start time. You may enter up to 12 start times for each Schedule.

Note that Military Time is used. 20:00 therefore equals 8:00 PM.





Integration Scheduler

Status	Name	Week Days	Start	Method	Budget (%)	Time (min)	Rec's	Sim. Time
Revised	Added	-----S-----	1	Added	100	Time	0	0:00
Revised	TEST	-----S-----	1	Sequential	100	Time	10	0:00
Revised		-----S-----	0	Sequential	100	Time	0	0:00
				Priority				
				Automatic				

Methods

In the "Method" field select Sequential.

See page 26 for explanation of "Sequential", "Priority" and "Automatic".

Contents of TEST

Name	Type	Min	max	ET
Decoder	Decoder	0	0	
Encoder	Encoder			
Encoder	Encoder			

Contents of TEST

Name	Type	Min	max	ET
L1	Decoder	0	0	
L2				
L3				
L4				
L5				
01				
02				
03				
04				
05				
06				

Contents of TEST

Name	Type	Min	max	ET
L1	Decoder	10	0	

Contents of TEST

Name	Type	Min	max	ET
L1	Decoder	15	0:00	
L2	Decoder	16	0:00	
L3	Decoder	15	0:00	
L4	Decoder	15	0:00	
L5	Decoder	16	0:00	
01	Decoder	12	0:00	
02	Decoder	12	0:00	
03	Decoder	13	0:00	
04	Decoder	16	0:00	
05	Decoder	12	0:00	
06	Decoder	12	0:00	
		0	0	0

Line Decoder

From the drop down list under "Types" you may choose between Decoder or Sector, in this case select Decoder.

Read about **Sectors** on page 24.

Select the Decoder from the drop down list under Name. Names that have already been included in the schedule are removed from the list.


Minutes

Click on the "Min" field and enter the desired run time (in minutes) for the valve.

Delete Decoder

If you want to delete a Decoder from a schedule, click on the grey "border field" left to the Decoder. The line is now marked with a black arrow. The press the delete button.

To complete the deletion, click the Yes button in the Warning window.



Name	Type	Min	min	ET
L1	Decoder	15	0.00	
L2	Decoder	16	0.00	
L3	Decoder	15	0.00	
L4	Decoder	15	0.00	
L5	Decoder	16	0.00	
B1	Decoder	12	0.00	
B2	Decoder	12	0.00	
B3	Decoder	12	0.00	
B4	Decoder	16	0.00	
B5	Decoder	12	0.00	
B6	Decoder	12	0.00	
		0	0	0


Dry Run (Simulation)

When a new schedule is created or a schedule is changed, the duration in the field "Sim Time" is marked with a star. Click on the field to (re)calculate the run time. This will bring up the Dry Run table shown below.

Status	Name	Work Days	Score	Method	Budget (%)	Time (min)	Rec'd	Sim Time
Ready	Admitt	-----S-----	1	Admitt	100	Time	0	0:00
Ready	TEST	-----S-----	1	Sequential	100	Time	0	0:00
Ready		-----S-----	0	Sequential	100	Time	0	0:00

In the table all times are shown relative to the start time (00:00). Notice that there is a delay of one minute from the schedule is started and till the first decoder starts. Also valves start/stop at the full minute only. The first minute is used by theFlow Optimizer to calculate how the valves must be started. If you click on the leftmost button, marked graph, you will get the pump load curve (See the next page.)


Day	Time	Value	Action	Pump (gpm)
1	00:00	TEST	START	
1	00:01	L1	STARTED	10.0
1	00:02	L1	STOPPED	0.0
1	00:03	L2	STARTED	10.0
1	00:04	L2	STOPPED	0.0
1	00:05	L3	STARTED	10.0
1	00:06	L3	STOPPED	0.0
1	00:07	L4	STARTED	10.0
1	00:08	L4	STOPPED	0.0
1	00:09	L5	STARTED	10.0
1	00:10	L5	STOPPED	0.0
1	00:11	B1	STARTED	10.0
1	00:12	B1	STOPPED	0.0
1	00:13	B2	STARTED	10.0
1	00:14	B2	STOPPED	0.0
1	00:15	B3	STARTED	10.0
1	00:16	B3	STOPPED	0.0
1	00:17	B4	STARTED	10.0
1	00:18	B4	STOPPED	0.0
1	00:19	B5	STARTED	10.0
1	00:20	B5	STOPPED	0.0
1	00:21	B6	STARTED	10.0
1	00:22	B6	STOPPED	0.0



The graph shows how the flow varies during the schedule. The heading shows total flow and total time. When the cursor is moved in the graph, the coordinates are shown in the field in the bottom of the window.

Irrigation Methods


The Irrigation method is by default sequential when you create an Irrigation schedule, but you will probably prefer to use automatic or priority because they lead to shorter watering times.



Status	Name	Week Days	Start	Method	Valve(s)	Time/area	Next	Run Time
Pending	Added	-----0-----0	1	Automatic	100	Time	0	00:00
Pending	TEST	0-1-----0---	1	Sequential	100	Time	0	00:00
Pending		-----0-----0	0	Sequential	100	Time	0	00:00
Pending		-----0-----0	0	Sequential	100	ET Control	0	00:00

Sequential Method

The valves are activated one at a time, in order as listed in the Demo program and beginning at the top of the list. The graph on top shows sequential method for our TEST schedule. Note that the total duration is 2:06. The Flow Optimizer is not used and even if you make the mistake to place a valve that requires more water than the pipe's capacity, the schedule will run.




Priority Method

Again the valves are activated in order as listed, but this time as many as the flow data allows for. Note that the total duration is 0:47. If there are mistakes in the flow data (too large valve on too small pipe) the schedule will not run! This method is of course more efficient than the sequential but still has the advantage that the order in which the valves are started is well known.



Automatic Method

The Flow Optimizer calculates the optimum number and order in which to activate the valves, trying to utilize fully, as much of the time as possible, the maximum water capacity of the system. Note that the total duration is now 0:32. The only problem is that the valves seem to come on at random, which makes it hard to figure out which will come on next.



Start Irrigation

Schedule status

Select the status field to get the drop down menu and select "Active" to change the schedule status from passive to active. Only active schedules will run when Irrigation is turned ON.

When you set schedules to "Passive", they are stored for later use and will not be executed when Irrigation is ON.

Status	Name	Week Days	Start	Method	Budget (%)	Time/min	Reck	Sim Time
Active	Active	-----S-----	1	Active	100	Time	0	0:00
Active	ECI	-----S-----	1	Sequential	100	Time	1	0:00
Active		-----S-----	0	Sequential	100	Time	0	0:00

Irrigation ON


Even schedules with status "Active" will not run until the Irrigation is turned ON.

Select "Status" from the View-menu and click on the "ON" button. The field with Irrigation Status will now change to "Irr On".



Irrigation OFF


Irrigation may be turned off in two ways. By clicking on the "Off"-button the system is reset to Irrigation Off immediately and execution of all schedules are stopped. By clicking on the "Off when idle"-button, system is changed to Irrigation Off but the current schedule will be completed as programmed.



Status	Name	Week Days	Start	Method	Budget (%)	Time (min)	Reck	Sim. Time
Revised	Added	-----0-----0	1	Added	100	Time	0	0:00
Revised	TEST	0-0-----0-	1	Sequential	100	Time	1	0:00
Revised		-----0-----0	1	Sequential	100	Time	0	0:00

Updating window

Some fields, f. inst. the Sim. Time, are not updated automatically. Press <F5> to get the window completely updated. This will also rearrange the schedules so that active schedules are moved to the top of the list (and in alphabetical order).



Day	Time	Schedule	Action	Status
1	00:00	TEST	START	
1	00:44	TEST	FINISH	
1	00:00	TEST	START	
1	01:00	TEST	START	Rejected
1	01:00	TEST	FINISH	Rejected
1	00:44	TEST	FINISH	
1	00:00	TEST	START	
1	00:44	TEST	FINISH	


Schedule overlap

TWC-500 can only run one schedule at a time. If you have overlapping schedules only the one already running when the second comes to start, will be executed, the second will be rejected.

To test that click the "Dry Run, All" button.

The table shows clearly which Schedules are overlapping and which one is rejected.

To resolve the conflict, change start time for one or more schedules.



In the graph the schedules that run are blue and the rejected are marked with red.



Water Budget

Water budget allows you to adjust the watering time from 0-300 %. a Water Budget of 100 % means that the irrigation will be carried out as initially programmed. In this TEST schedule you will get 3 times the minutes that you keyed in with the decoders. The 100 % should correspond to normal watering time. In dry periods, setting WB to 150 % would give you 50 % more water.

ID	Status	Name	Workdays	Start	Method	Budget (%)	Time/min	Sec's	Sec/Tot
1	Active	DEMO	---4---	1	Sequential	100	Time	1	00:07
2	Active	TEST	0-4---	1	Sequential	300	Time	3	07:43
3	Pause	Admtest	---4---	1	Parallel	100	Time	4	00:02
4	Pause		---4---	4	Sequential	100	Time	4	00:02

Time Window

Time Window prevents schedules from watering within a certain time frame called the Window. This means that a running schedule will be terminated when the Time Window starts. Manual operation of schedules and decoders are still possible. Note that the Irrigation Status field changes to "Closed" when within the window (and Irrigation is ON).

Irrigation Status

Date & Time: Fri Jul 14 (12) 11:39:11 2000

Irrigation Status: **Closed**

Start/Stop Schedules:

Time Window:

Irrigation will be closed from: 06:00 to: 18:00

Manual Start/Stop

Decoder Start

Select from the "Manual" menu Decoder Start/Stop. In the control window select the desired Decoder from the list. The list is sorted in alphabetical order. Enter the duration and click on the Start button.

Decoder Stop

Select from the list the desired Decoder and click on the Stop button.

Stop All Decoders

Click on the Stop All button. This will also stop all decoders that are activated by a schedule.




Manual Decoder Control

Select Line Decoder:


- B4
- B5
- B6
- L1**
- L2
- L3
- L4
- L5

Duration: 5 Minutes



Schedule Start/Stop

Select the schedule and click on the Start or the Stop button.



Display Man. started Decoders



Monitoring



This window lists all events in order of time. Use the scroll slider to move up and down in the list. All events are recorded to a file on the PC's harddisk.


When the PROCOM Central unit is "Off line" (not in contact with your PC), it still records events to memory in the TWC-500. The recordings are transmitted to the PC next time they are "On line". The TWC-500 can store at least 2.500 lines.

The monitor window shows the name of the unit, action, date & time and the flow total.

Print Monitoring

If you click on the "copy" button the content of the monitor log is copied to the Windows clipboard. From there it can be pasted to the wordprocessor of your choice, and then printed.






Logviewer

To work with the monitoring data you must use the function Extract and view monitor log.

The data can not be extracted unless you are connected with the controller.

When you select this menu point, the program "Logviewer" which is an Excel macro will be started. If your security system prompts you that the program contains macros that might contain virus, you must say yes to start these.

For this to run properly you need Excell 7 or later and Windows 98 or later.



If you are connected to the controller the TWC program will look for the spreadsheet program Excel. If it is installed on your PC, the program "Logviewer" which is an Excel macro will be started. (If your security system prompts you that the program contains macros that might contain virus, you must say yes to start these.) The monitoring data will automatically be imported into Excel. Activity bars will keep you informed of the progress in the import and conversion of the data.

Microsoft Excel - view.xls

File Edit View Insert Format Tools Data Window Help

A09

	A	B	C	D	E	F	G	H	I	J
105										
106		08-02-01	FLOW	07:00 AM	07:07 AM	7	290.0			
107			FLOW	08:00 AM	08:07 AM	7	290.0			
108			FLOW	08:30 AM	08:37 AM	7	290.0			
109	****		Manually Started	04:29 AM		298	225.0			
110			No name	04:36 AM		0	0.0			
111			TEST	05:00 AM	05:45 AM	45	2676.0			
112		08-02-01		Total		314	3771.0			
113										
114										
115										
116										
117										
118										
119										
120										
121										
122										
123										
124										
125										
126										
127										
128										
129										
130										

S-RAIN

File View Commands

Use the custom menu to view the overview-sheet or data-sheet.

Microsoft Excel - data.xls

File Edit View Insert Format Tools Data Window Help

A103

	A	B	C	D	E	F	G	H
136								
137		09:02:01		05:00 AM	05:01 AM	1	-	
138				05:01 AM	05:11 AM	10	125,0	1260
139				05:11 AM	05:15 AM	4	125,0	500
140				05:15 AM	05:16 AM	1	127,0	127
141				05:16 AM	05:17 AM	1	127,0	127
142				05:17 AM	05:18 AM	1	15,0	15
143				05:18 AM	05:20 AM	2	15,0	30
144				05:20 AM	05:21 AM	1	16,0	16
145				05:21 AM	05:29 AM	8	15,0	120
146				05:29 AM	05:30 AM	1	15,0	15
147				05:30 AM	05:32 AM	2	14,0	28
148				05:32 AM	05:33 AM	1	14,0	14
149				05:33 AM	05:35 AM	2	14,0	28
150				05:35 AM	05:36 AM	1	15,0	15
151				05:36 AM	05:37 AM	1	15,0	15
152				05:37 AM	05:45 AM	8	47,0	396
153				05:45 AM	05:45 AM	0		
154		09:02:01		Total		45		2676
155								
156								
157								
158								
159								
160								


Use the custom menu to view the overview-sheet or data-sheet.

Sector

Sectors are groups of Decoders that should be treated in the same way. It is a tool to expedite data input when you set up an Irrigation schedule.

In this example a sector (BEDS) is created with 4 Decoders that will normally run together and for the same time.

Though a Decoder is included in a sector it may still be included in schedules as an individual.



Select Display/Modify Sector. In the Sector Edit window select the first field (with Total) and write the sector name.

Now click on the Decoders field in the "BEDS" line. This will open a new window, "Decoders display"

Click on the first field (Total) and write the name of the first Decoder. To add another Decoder, press <Enter> until the next field becomes selected and write the next name.

If you key in a non existing name, this message will occur.




When you are finished with your sector, close the window.


Name	Capacity	Parent
01	600 0000	0000 0000
02	600 0000	0000 0000
03	600 0000	0000 0000
Total	2400 -	

Delete Sector member

If you want to remove a member of a sector, click on the grey border left to the line. The line is now marked with a black arrow. Decoder and press the Delete button.

You must click on the Yes button in the warning window to complete the deletion.







Pump Status

The pump status has three modes:

- Not installed
- Active
- Passive

The picture shows that only Pumps 1 and 2 (with Pump Decoders) have been installed. Their status are now "Active". This means that these two pumps will be used during irrigation. "Passive" means that a pump is installed, but is temporarily out of operation (for repair or maintenance). The system will correct for reduced pump capacity during irrigation. If you change the status of a pump it will affect the time needed to carry out irrigation. It is therefore advisable to make a Dry Run.

Note that the status of pumps can only be changed while the system is in Irrigation off mode.



Sensor Status

The sensors status has three modes:

- Not installed
- Used
- Not used

If, for example, you want to prevent your Rain sensor from stopping the irrigation, it is not necessary to disconnect it. Just change the status to "Not used".

The table also shows when a sensor was ON last time and when it went OFF again. If a sensor is on when you select this function, no OFF time will appear.




User password

The User password is set up in exactly the same way as the Installers Password, see page 6-7.

Once the User Password is activated, the system asks for it before changes can be made in the following:


- Irrigation Start/Stop
- Start/Stop of valves
- Password
- Date and Time
- Sectors
- Pump and Sensor status
- Modify Irrigation Schedule
- Time Window





This page is intentionally blank.


PROCOM Main Parts



System Components



LTB-500
Line Termination Box



LTB-500/CB
Circuit Board for LTB-500

Line Decoders




ID-100

ID-200

ID-400

ID-600

SP-100 Surge Protection





SD-100
Sensor Decoder



PD-100
Pump Decoder

MOP-1
Modem cables

MOP-1



OC-100
Optical Isolator





FA-100
Field Access Unit



FAB-100
Field Access Unit connection box



PROCOM Specifications

Hardware specifications:

System capacity	50, 100, 200, 300, 400, 500 decoders
Valves operating simultaneously	40
Electrical input	24 VAC from security transformer, 50-60 Hz, 100 VA
Electrical output	33 V square wave
Signal cable	2-wire double insulated
Main processor	NEC type V40, 16 bit microprocessor
Storage components:	
Main system program	128 kB EPROM + 256 kB FLASH-ROM
Installation Data	64 kB S-RAM
Working memory	512 kB RAM
Battery Backup	Clock/calendar and Installation Data
Environment	Office: 41 F to 86 F 20 to 80 % humidity

Software specifications:

Irrigation Schedules	30
Start times	Each schedule: 12 times per day
Timing	0-999 minutes, in one minute steps
Programming cycle	14 days
Operation methods	Sequential, Priority, Automatic
Sectors	150
Dry Run	Simulation on screen
Monitoring	Monitoring on screen and with Logviewer to print/reports
Manual operation	Full manual operation of Decoders/Schedules
Main Pipe sections	100
Valve types	100
Pump control	Full automatic control of 6 Main Pumps + 9 Booster pumps Special Pump Decoder available
Sensors	Direct wired sensors: Rain Sensor Aux. Sensor Line monitoring: Line current Leakage current Sensor decoder: 10 Sensor Decoders for flow monitoring with high-flow and leakage alarms
Field Control	Operation of Field Access Unit FA-100 supported
Languages supported	Currently english only, other languages available on request.
Measurement units	Gallons , inches, m3, liters, mm

Index

A

Automatic Method 27
Automatic testing 16

C

Central Unit, connections 3
Connect 14

D

Date and Time 10
Decoder Start 29
Decoder Stop 29
Delete Decoder 25
Delete Sector member 35
Dry Run 25

F

Flow Monitoring 12
Flow Sensor 10

G

GF signal 18
GF Solenoids 17

I

Installation of software 4
Installers Password 6
Irrigation Methods 26
Irrigation OFF 27
Irrigation ON 27
Irrigation Schedules 23

L

LD Thorough 19
Line Decoder 20, 24
Line Decoders 8
Line Survey 22
Line Voltage 10
Logviewer 32

M

Main Pipe 7
Man. started Decoders 30
Manual Start/Stop 29
Manual Tests 20
Menu Tree 5
Methods 24
Minutes 24
Modem connection 14

Monitoring 31

N

New Pipe 7

P

Parameters 6
Print Monitoring 31
Priority Method 26
Pump Decoder 9
Pump Status 36

R

Remove password 7

S

Schedule Name 23
Schedule overlap 28
Schedule Start/Stop 30
Sector 34
Sensor Inputs 9
Sensor Status 36
Sequential Method 26
Short Circuit 10
Short Finding 21
Simulation 25
Solenoid resistance 15
Start Irrigation 27
Start Times 23
Stop All Decoders 29
System Layout 2

T

Test of installation 15
Time Window 29
Transfer of Data 13
True monitoring 15
TWC-500 Main Parts 39
TWC-500 Specifications 45
Type of Valves 8

U

Updating window 28
User password 37

W

Water Budget 29
Week Days 23

